



KS5970V1 11/02

ADEMCO 165 Eileen Way, Syosset, New York 11791
Copyright © 2002 PITTWAY CORPORATION

Disarm: User Code + [1]
Arm Away: User Code + [2]
Arm Stay: User Code + [3]
Arm Away or Stay with No Delay: User Code + [2] or [3] + [0]
Turn on 1-6: [#] + [4] + Dev. No.
Turn on 7 & 8: User Code + [#] + [4] + Dev. No.
Turn off 1-6: [#] + [7] + Dev. No.
Turn off 7 & 8: User Code + [#] + [7] + Dev. No.
Bypass a zone(s): User Code + [6] + zone no.
Activate Quick Bypass: User Code + [6] + [#]
Check system: [1]
Hang up: User Code + [9]

Remote Phone Control

LYNXR-EN

SYSTEM FUNCTIONS REFERENCE CARD

This card lists the most common user functions. For further information, refer to User Guide.

Security Functions

Check system: **[STATUS]**
Arm Stay: Press and hold **[STAY]** or User Code + **[STAY]**
Restart exit delay: **[STAY]**
Arm Away: Press and hold **[AWAY]** or User Code + **[AWAY]**
Arm No Delay: Press and hold **[AWAY]** or **[STAY]** + **[NO DELAY]**
or User Code + **[AWAY]** or **[STAY]** + **[NO DELAY]**
Disarm & silence alarms: User Code + **[OFF]**
Bypass a zone(s): User Code + **[BYPASS]** + Zone No.
Chime mode on or off: **[FUNCTION]** + **[CHIME]**

Message Center

Record a message: **[FUNCTION]** + **[RECORD]**
Stop recording: **[OFF]**
Play back a message: **[FUNCTION]** + **[PLAY]**
Adjust volume: **[FUNCTION]** + **[VOLUME]** + [3] or [6]
Mute announcements: **[FUNCTION]** + **[VOLUME]** + **[OFF]**
Restore announcements: **[FUNCTION]** + **[VOLUME]** + [3]
Delete all messages: **[FUNCTION]** + **[DELETE]** (During message replay)

Speaker Phone Operation

To place or answer a call using the speaker phone: [#] + **[AUX]**
Flash (switch between two calls using call waiting): **[AUX]**
To hang up: **[OFF]**
Enable/disable (toggle) ringer: [#] + **[VOLUME]** + **[AUX]**
Return keypad to telephone mode: [#] + **[AUX]**

Other Functions

Set the time and date: User Code + **[FUNCTION]** + [63]
Add a user code: Master Code + **[CODE]** + User No. + User Code
Delete a user code: Master Code + **[CODE]** + User No.
Test mode on: User Code + **[TEST]**
Test mode off: User Code + **[OFF]**
Use the AUX function: Press and hold **[AUX]** key 2 secs. + User Code
Send message to pager: Press and hold **[AUX]** key 2 secs. (if programmed)
Turn ON/OFF 1-6: **[FUNCTION]** + **[LIGHTS ON]** + Dev No. or **[LIGHTS OFF]** + Dev No.
Turn ON/OFF 7-8: **[FUNCTION]** + **[LIGHTS ON]** + Dev No. or **[LIGHTS OFF]** + Dev No.
Program/Delete Follow Me phone number: User Code + **[FUNCTION]** + [65]

More Information on other side